



Spring Return Signposts: Replacing the Removable Post 1

Fitting a Post to an Installed Base:




Removing Post from Installed Location:




Spring Return Signposts: Replacing the Removable Post 2

Fitting a Post prior to Installing Base:



Tightening Grub Screws



Selecting the Correct Grub Screws

